



## Call Parking

Santiago Garcia - 2024-07-22 - Advanced

### Call Parking

Call park is a feature that allows a person to place a call to a '*parking bay*' enabling a coworker to retrieve the call from alternate phone, or BLF presence key. The parking bay is usually set against the main number, enabling the parked call to be returned to the main number if it exceeds the allocated parking bay time.

In the example below we have enabled Call Parking on the customers main phone number 1-760-68-8100. The customer can set 10 parking slots.

The screenshot shows a configuration window for 'Call Parking'. At the top left is the title 'Call Parking' with a help icon. At the top right is an expand/collapse arrow and a toggle switch that is currently turned on. Below the title are five configuration fields: 'First extension' with a dropdown menu showing '700'; 'Parking slots' with a text input '10' and a label 'slots'; 'Parking Time' with a text input '120' and a label 'sec'; 'Return call to' with a dropdown menu showing 'The number that parked'; and 'Group' with a text input 'Default'. At the bottom of the form are two buttons: 'CANCEL' and 'SAVE'.

Pete L and Rajesh's Yealink phones have been programmed to use Line 3 and LineKey 4 for Parking Bays 1 & 2 (see) Setup Call Parking below.



## How to set up Call Parking

1. Select Switchboard | Select your number.
2. Select Advanced | Call Parking.
3. Add how many Parking slots you'd like to have, e.g 10.
4. Add the Parking Time, e.g 240 sec.
5. Set up the Return Call to a specific number or to the number that parked the call.
6. The group goes by default.
7. Click Save to update your settings.

## Park a call and send it to a Specific Bay

One of the options we have to set up Call Parking is when you park a call to be taken on a specific park bay.

The Call Park garages required a **\*1 short code** to call the bays. In the example above, we therefore must assign **\*1701** and **\*1702** for Parking 1 and Parking 2 respectively.

Now that you have set up the Call Parking feature, choose one of the two options to configure on your handset to park and retrieve calls.

## How to Park and Retrieve calls - Specific Bay

- **To park** the call and send it specifically for Bay 2, press BFL Bay 2 on your handset or dial \*1702. (NB - the Parking Attendant will confirm your parking slot).
- **To retrieve** the call from Bay 2, press BFL Bay 2 on your handset or dial \*1702.

## Yealink Device Provisioning

Using our Device Provisioning simplifies the process for enabling Call Parking onto any Yealink phone provisioned with our device provisioning.

LINE	TYPE	NUMBER	LINE NAME		
Line Key 1	Number	17605588991	Myles	Line 1	
Line Key 2	BLF	17605588992	Dispatch 1	Line 1	
Line Key 3	BLF	17605588993	Dispatch 2	Line 1	
Line Key 4	BLF	17605588994	BreakRoom	Line 1	
Line Key 5	BLF	17605588990	Julie	Line 1	
Line Key 6	Call Park	*1701	Parking 1	Line 1	
Line Key 7	Call Park	*1702	Parking 2	Line 1	

+ Add line

Etiquetas

Advanced