![2talk logo]

Grandstream - Manual Provisioning

Mike Johnstone - 2024-10-28 - [Handsets and Device Provisioning](#)

Grandstream – Configuring your phone

Quick Guide to Grandstream

In addition to the Grandstream ATA 80x we now support Grandstreams latest GRP handsets via our device provisioning.

- Retrieve the phones IP address > select the Settings button (highlighted below)

- Status | Network Status | Ethernet | IPV4 address

- Advanced settings: in browser type http:/**<address>** to access web admin mode.

Select Settings

Status

Network Status

Ethernet

 IPV4 Address

Ext tabs

All the main settings required to configure the Cisco SPA's are accessed within the Ext tabs. Complete:

1. General Setting

- Activate Account: Enable

- Account Name: Can phone and owner name (eg Sally)

- SIP user ID: Phone number

- SIP Auth ID: Phone number

- SIP server: call.sipcity.com.au

2. SIP setting (tab)

- SIP Registration: Enable

- Subscribe Exp: 60

- SIP Transport: TLS

- Local SIP port: 5061

Accounts

General Settings   SIP Settings   Codec Settings   Call Settings   Advanced Settings   Dial Plan   Hidden Number Plan   Feature Codes

Account Register

Account Active ⑦	☑
Account Name ⑦	19497993303
SIP Server ⑦	call.sipcity.com.au
Secondary SIP Server ⑦	
Outbound Proxy ⑦	
Secondary Outbound Proxy ⑦	
SIP User ID ⑦	19497993303
SIP Authentication ID ⑦	19497993303
SIP Authentication Password ⑦	••••••
Name ⑦	GD 3303
Tel URI ⑦	Disabled
Voicemail Access Number ⑦	
BLF Server ⑦	
Account Display ⑦	Username
UCM User Password ⑦	