



## Device Provisioning - Grandstream ATA

Santiago Garcia - 2024-04-10 - Device Provisioning

# Device Provisioning - Grandstream ATA

Registering your **Grandstream** in our **Device Provisioning** ensures that you can get your Grandstream up and running in minutes.

1. Log into your [account](#).
2. Click on **Tools | Device Provisioning**.
3. Choose **Add Device**.
4. Select **Device Type** (Grandstream type).
5. **Line Settings | Select Phone Number | Grandstream | Name Device**
6. Supply **MAC address**.
7. Add **Time zone | Time Format**
8. Line Key2: Select **Number or Feature**
9. If this is a BYO Yealink Select '**SAVE**' and manually restart the handset.
10. Once provisioned by our Device Provisioning any further changes made from within the portal will automatically restart the handset to reflect your changes

## Add device

↑ Yealink Bulk upload

Line settings	19525250273 ▾	Grandstream HT81X ▾	Bosley Mannetonka
Line settings	19525250274 ▾	Grandstream HT81X	0274
Line settings	19525250275 ▾	Grandstream HT81X	0275
Device settings	c074ad9d15ec	207GjSNN519D15EC	
Time settings	America/New_Y... ▾	12 ▾	