

<u>Knowledge Base</u> > <u>Handsets and Device Provisioning</u> > <u>Grandstream Manual setup</u>

Grandstream Manual setup

Mike Johnstone - 2024-10-28 - Handsets and Device Provisioning

Grandstream - Configuring your phone

Quick Guide to Grandstream

In addition to the Grandstream ATA 80x we now support Grandstreams latest GRP handsets via our device provisioning.

- Retrieve the phones IP address > select the Settings button (highlighted below)
- Status | Network Status | Ethernet | IPV4 address
- Advanced settings: in browser type http:/<address> to access web admin mode.



Select Settings

Status
Network Status
Ethernet
IPV4 Address

1. General Setting

- Activate Account: Enable
- Account Name: Can phone and owner name (eg Sally)
- SIP user ID: Phone number
- SIP Auth ID: Phone number
- SIP server: call.sipcity.com.au
- 2. SIP setting (tab)
 - SIP Registration: Enable
 - Subscribe Exp: 60
 - SIP Transport: TLS
 - Local SIP port: 5061

