

Grandstream Manual setup

Mike Johnstone - 2024-10-27 - Handsets and Device Provisioning

Grandstream - Configuring your phone

Quick Guide to Grandstream

In addition to the Grandstream ATA 80x we now support Grandstreams latest GRP handsets via our device provisioning.

- Retrieve the phones IP address > select the Settings button (highlighted below)
- Status | Network Status | Ethernet | IPV4 address
- Advanced settings: in browser type <http://<address>> to access web admin mode.



1. General Setting

- Activate Account: Enable
- Account Name: Can phone and owner name (eg Sally)

- SIP user ID: **Phone number**
- SIP Auth ID: **Phone number**
- SIP server: **call.sipcity.com.au**

2. SIP setting (tab)

- SIP Registration: **Enable**
- Subscribe Exp: **60**
- SIP Transport: **TLS**
- Local SIP port: **5061**

Accounts

Account 1
Account 2
Account 3
Account 4
Account 5
Account 6

General Settings
SIP Settings
Codec Settings
Call Settings
Advanced Settings
Dial Plan
Hidden Number Plan
Feature Codes

Account Register

Account Active ?

☒

Account Name ?

19497993303

SIP Server ?

call.sipcity.com.au

Secondary SIP Server ?

Outbound Proxy ?

Secondary Outbound Proxy ?

SIP User ID ?

19497993303

SIP Authentication ID ?

19497993303

SIP Authentication Password ?

.....

Name ?

GD 3303

Tel URI ?

Disabled

Voicemail Access Number ?

BLF Server ?

Account Display ?

Username

UCM User Password ?