



Grandstream - Manual Provisioning

Mike Johnstone - 2024-10-27 - Handsets and Device Provisioning

Grandstream - Configuring your phone

Quick Guide to Grandstream

In addition to the Grandstream ATA 80x we now support Grandstreams latest GRP handsets via our device provisioning.

- Retrieve the phones IP address > select the Settings button (highlighted below)
- Status | Network Status | Ethernet | IPV4 address
- Advanced settings: in browser type <http://<address>> to access web admin mode.

Ext tabs

All the main settings required to configure the Cisco SPA's are accessed within the Ext tabs. Complete:

1. General Setting

- Activate Account: Enable
- Account Name: **Can phone and owner name (eg Sally)**
- SIP user ID: **Phone number**
- SIP Auth ID: **Phone number**
- SIP server: **call.sipcity.com.au**

2. SIP setting (tab)

- SIP Registration: **Enable**

- Subscribe Exp: 60
- SIP Transport: TLS
- Local SIP port: 5061