



## Grandstream Manual setup

Mike Johnstone - 2024-10-28 - [Handsets and Device Provisioning](#)

### Grandstream - Configuring your phone

#### Quick Guide to Grandstream

In addition to the Grandstream ATA 80x we now support Grandstreams latest GRP handsets via our device provisioning.

- Retrieve the phones IP address > select the Settings button (highlighted below)
- Status | Network Status | Ethernet | IPV4 address
- Advanced settings: in browser type `http://<address>` to access web admin mode.



#### Select Settings

- Status
- Network Status
- Ethernet
- IPV4 Address

1. General Setting

- Activate Account: **Enable**
- Account Name: **Can phone and owner name (eg Sally)**
- SIP user ID: **Phone number**
- SIP Auth ID: **Phone number**
- SIP server: **call.sipcity.com.au**

2. SIP setting (tab)

- SIP Registration: **Enable**
- Subscribe Exp: **60**
- SIP Transport: **TLS**
- Local SIP port: **5061**

## Accounts

Account 1 Account 2 Account 3 Account 4 Account 5 Account 6

General Settings SIP Settings Codec Settings Call Settings Advanced Settings Dial Plan Hidden Number Plan Feature Codes

### Account Register

Account Active

Account Name

SIP Server

Secondary SIP Server

Outbound Proxy

Secondary Outbound Proxy

SIP User ID

SIP Authentication ID

SIP Authentication Password

Name

Tel URI

Voicemail Access Number

BLF Server

Account Display

UCM User Password