



## Grandstream - Manual Provisioning

Mike Johnstone - 2024-10-27 - Handsets and Device Provisioning

# Grandstream - Configuring your phone

## Quick Guide to Grandstream

In addition to the Grandstream ATA 80x we now support Grandstreams latest GRP handsets via our device provisioning.

- Retrieve the phones IP address > select the Settings button (highlighted below)
- Status | Network Status | Ethernet | IPV4 address
- Advanced settings: in browser type `http://<address>` to access web admin mode.

### Ext tabs

All the main settings required to configure the Cisco SPA's are accessed within the Ext tabs. Complete:

#### 1. General Setting

- Activate Account: Enable
- Account Name: Can phone and owner name (eg Sally)
- SIP user ID: Phone number
- SIP Auth ID: Phone number
- SIP server: `call.sipcity.com.au`

#### 2. SIP setting (tab)

- SIP Registration: Enable

- Subscribe Exp: 60
- SIP Transport: TLS
- Local SIP port: 5061