



## Polycom Manual Configuration

Santiago Garcia - 2024-04-09 - Polycom Devices

# Polycom Manual Configuration

### Manual configuration

You can quickly configure a handset by supplying four simple pieces of information in 2.1 with all other steps being optional.

1. Retrieve the handset IP address: Home (Button) > Settings > 4. Status > 2. Network > 1. TPC/IP.
2. Web UI: Enter IP address (eg 192.168.1.11) into your browser.
3. Settings > Lines (select Line).

Follow instructions from the image below

1. SIP Protocol: Enable.
2. Identification: Display Name, Address (must be full DID), Label (usually same as Display Name).
3. Authentication: User ID (full DID), Phone's password from your switchboard, Disable Credentials.
4. SIP Server 1: plus.2talk.com – Expires 180

Line 1

SIP Settings

SIP Protocol ☒ Enable ☐ Disable

H.323 Settings

Identification

Display Name

MikeJ

Address

13106341780

Label

Mike

Type

☒ Private ☐ Shared

Third Party Name

Number of Line Keys

1

Calls Per Line

24

Enable SRTP

☒ Yes ☐ No

Offer SRTP

☐ Yes ☒ No

Require SRTP

☐ Yes ☒ No

Server Auto Discovery

☒ Enable ☐ Disable

Authentication

Use Login Credentials

☐ Enable ☒ Disable

Domain

User ID

13106341780

Password

\*\*\*\*

Outbound Proxy

SIP Server 1

Special Interop

Standard

Address

plus.2talk.com

Port

5061

Transport

DNSnaptr

Expires (s)

180

Subscription Expires (s)

180

Register

☒ Yes ☐ No

Retry Timeout (ms)

0

Retry Maximum Count

3

Line Seize Timeout (s)

30

Etiquetas

Device

Polycom