

Base de conocimiento > Handsets and Device Provisioning > Yealink Devices > Yealink Dect Cordless handset provisioning

Yealink Dect Cordless handset provisioning

Mike Johnstone - 2024-07-11 - Yealink Devices

Yealink Dect Cordless handsets

Supports W52, W56, W70, W76

Yealink DECT handsets are compatible with our <u>device provisioning</u> system. However, to complete the installation you'll need to manually pair each handset with its base station. This final one minute step, is not covered by Yealink's automatic provisioning services.



- Step 1: Base Station Press and hold < Pager Button>
- Step 2: Handset Press < Reg key>
- Step 3: Handset status > Easy Pairing
- Step 4: Handset status > Handset Subscribed
- Step 5: Handset Handset Registered

Factory Reset

If you are bringing a used Yealink DECT handset to 2talk we recommend first factory resetting the unit.

Press OK to enter the main menu.

- Step 1: Select Settings>System Settings>Base Reset.
- Step 2: Enter the system PIN (default: 0000), and then press the Done soft key.
- Step 3: Highlight Reset to factory, and then press the OK soft key.
- Step 4: The resetting process may take a few minutes. Do not power off until the base station starts up successfully.

See also: Yealink Device Provisioning