



## Device Provisioning - Yealink

Santiago Garcia - 2024-07-17 - Device Provisioning

# Device Provisioning - Yealink

Registering your **Yealink** in our **Device Provisioning** ensures that you can get your Yealink up and running in minutes.

- Log into your account > Tools | Device Provisioning.
- Choose Add Device > Select Device Type (Yealink).
- Line Settings | Select Phone Number | Yealink | Name Device
- Supply MAC address.
- Add Time zone | Time Format
- Line Key2: Select Number or Feature

If this is a BYO Yealink Select 'SAVE' and manually restart the handset.

Once provisioned by our Device Provisioning any further changes made from within the portal will automatically restart the handset to reflect your changes

### Add device

↑ Yealink Bulk upload

Line settings: 12134210003 Yealink Mike

Device settings: MAC address

Time settings: Time zone Time format

LINE	TYPE	NUMBER	LINE NAME		
Line Key 1	Number	12134210003	Mike	Line 1	🗑️
Line Key 2	BLF	12134210003	Susan	Line 2	🗑️
Line Key 3	Call Park	*1701	Bay 1	Line 3	🗑️

+ Add line

SAVE CANCEL

## Bulk Upload to Device Provisioning

You can now upload the numbers you would like to register to your Yealink using Device Provisioning from our template sheet.

- Click on **Yealink bulk upload**.
- Click on **(Download template)**. Then, the template will be downloaded. Click on the **Template** you have just downloaded.

Now, follow the steps to fill out the Sheet:

- Open the **Template** you previously downloaded.
- On the **MAC** column, fill out the **Yealink MAC Address**.
- On the **Number** column, fill out the **Number** you would like to register.
- On the **Label** column, fill out the **Label** for the number.
- To add more numbers under the same MAC Address, place numbers and labels on the columns aside.

Repeat steps 2 until 4 to add another **MAC Address** and **Numbers** you wish to register.

**Save** the file.

- Click on **Yealink bulk upload**. Select **Choose File** Select **Upload**.
- Wait until you receive a **Notification**
- Jump to your email to see the **Yealink Device Provisioning Update**. Check if you have received the failed or successful email.

**(Reboot)** your Yealink Device: Manually reboot your phone. After the first reboot, any changes made via the Device provisioning will automatically reboot the phone to apply any changes.

You are all set.

How Yealink's Device Provisioning works

Yealink's ZeroTouch provisioning is slick! From restart Yealink phones verify with Yealink's RPS (Remote Provisioning Service) if the phone has been associated with a partner RPS provisioning account. If so, Yealink inserts our provisioning URL

**(<https://yealink.2talk.com>)** against the phone's Provisioning settings. When phone reboots, it redirects with our Device Provisioning system, pulling in any assigned phone numbers or features set above.

To streamline, we've integrated this with Yealink RPS API. Once the MAC address has been entered against our Device provisioning system we link your MAC address to our RPS account.

